

DIRIS A17

Multifunction meters - MFM

Multi-measurement meter - dimensions 72 x 72 mm

Operating instructions **EN**



Contents

1. DOCUMENTATION3
2. DANGER AND WARNING3
2.1. RISK OF ELECTROCUTION, BURNS OR EXPLOSION3
2.2. RISK OF DAMAGING DEVICE3
3. PRELIMINARY OPERATIONS3
4. PRESENTATION4
4.1. MAIN FUNCTIONS4
4.2. DISPLAY VIEWS4
5. INSTALLATION5
5.1. RECOMMENDATION5
5.2. CUT-OUT DIAGRAM5
5.3. TERMINALS5
5.4. CONNECTIONS6
6. COMMUNICATION MODBUS®7
6.1. GENERAL INFORMATION7
6.2. RECOMMENDATIONS7
6.3. COMMUNICATION STRUCTURE7
6.4. REGISTER TABLE8
7. PROGRAMMING9
7.1. NAVIGATION PRINCIPLE9
7.2. ACCESS TO PROGRAMMING MODE10
7.3. EXAMPLE: NETWORK SELECTION11
7.4. EXAMPLE: CHOICE OF CURRENT TRANSFORMER12
7.5. PROGRAMMING MODE OVERVIEW13
7.6. DETAILED VIEW OF THE PROGRAMMING MENU14
8. USE18
8.1. DETAILED VIEW OF THE "CURRENT" MENU19
8.2. DETAILED VIEW OF THE "VOLTAGE" MENU20
8.3. DETAILED VIEW OF THE "POWER" MENU21
8.4. DETAILED VIEW OF THE "ENERGY" MENU22
9. CONNECTION TEST FUNCTION23
10. ASSISTANCE26
11. ELECTRICAL AND TECHNICAL CHARACTERISTICS27
12. ACCORDING TO IEC 61557-1228
13. GLOSSARY OF ABBREVIATIONS29

1. Documentation

All **DIRIS A17** documentations are available on the website at the following address:

www.socomec.com/en/documentation-diris-a17



2. Danger and warning

This equipment must be mounted only by professionals.

The manufacturer shall not be held responsible for failure to comply with the instructions in this manual.

2.1. Risk of electrocution, burns or explosion

- The device must be installed and serviced only by qualified personnel.
- Prior to any work on or in the device, isolate the voltage inputs and auxiliary power supplies and short-circuit the secondary winding of all current transfromers (PTI SOCOMEC).
- Always use an appropriate voltage detection device to confirm the absence of voltage.
- Replace all devices, doors, and covers before turning on power to this equipment.
- Always supply the device with the correct rated voltage.

Failure to take these precautions could cause serious injuries.

2.2. Risk of damaging device

Chek the following:

- the voltage of the auxiliary power
- the frequency of the distribution system (50 or 60 Hz)
- the maximum voltage across the voltage-input terminals, (V1, V2, V3 and VN) 500 VAC phase-to-phase or 289 VAC phase-to-neutral
- a maximum current of 6 A on the current-input terminals (I1, I2 and I3).

3. Preliminary operations

For personnel and product safety, please carefully read the contents of these operating instructions before installation.

Check the following points as soon as you receive the **DIRIS A17** package:

- the packing is in good condition,
- the product has not been damaged during transport,
- the product reference number conforms to your order,
- the package contains the product fitted with a pull-out terminal block and a Quickstart,

4. Presentation

The **DIRIS A17** is a 72x72 mm compact multifunction meter for measuring electrical network parameters. The **DIRIS A17** provides measurements of voltage, current, power and energy. With display and push buttons, users can easily access to all product functionalities. It includes an input and an output, and depending on the reference, it can include a communication bus as well as the measurement of the harmonic distortion rate.

4.1. Main functions


Multifunction meters - PMD*

- Measurement of electric variables: I, U, V, F
- Power, Power Factor and Energy
- THD (according to reference)
- 1 input / 1 output
- Alarms
- RS 485 MODBUS communication (according to reference)

Description	Reference
DIRIS A17 with pulse output	4825 0101
DIRIS A17 with RS485 Modbus communication	4825 0102
DIRIS A17 with RS485 Modbus communication and THD	4825 0103

*Performance Measuring and monitoring Device (IEC 61557-12)

4.2. Display views



1. Backlit LCD display.
2. Currents (instantaneous and maximum) and current THD.
3. Voltages, frequency and voltage THD.
4. Active, reactive, and apparent power (instantaneous and max. values) and power factor.
5. Powers.



- Geometric representation of active and reactive Power
Status of input/output
Bad phases order
THD IU Current or voltage THD measurement
Σ MAX Total power
COM Current or power max value
PROG In communication
ALARM Programming mode selection
Alarm presence

Zone 2

Electrical values measurement with Phases and/or Neutral indication

Zone 3

Total energy measurement


5. INSTALLATION

5.1. Recommendation


- avoid proximity to systems which generate electromagnetic interference,
- avoid vibrations with accelerations in excess of 1 G for frequencies below 60 Hz.

5.2. Cut-out diagram

- Panel mount of the device can be done according to the following cut-out diagram:




- Two fixing clips are used to fix the device to the panel.




5.3. Terminals

Each CT's secondary winding must be short-circuited when disconnecting the DIRIS. This can be done automatically using one of Socomec's catalogue products: the PTI (ref.: 4990 **0521**). Please contact us for further information.




5.4. Connections

5.4.1. Connection (input / output)



Power supply between 8 and 30 VDC for the input /output.


5.4.2. Communication connection




NC: not connected. can be used for shield continuity.

5.4.3. Network connections

5.4.3.1. Unbalanced three-phase network (4NBL)




5.4.3.2. Unbalanced three-phase network (3NBL)




The solution with 2 CTs with the 2nd and 3rd phase current calculated via vectorial summation, results in an 0.5% reduction in phase accuracy.

5.4.3.3. Balanced three-phase network (4NBL)



5.4.3.4. Balanced three-phase network (3NBL)





6. Communication MODBUS®

6.1. General Information

The MODBUS® communication bus is available on **DIRIS A17** (ref. 4825 0102 et 4825 0103).

It is achieved via an RS485 serial link (2 or 3 wires) for using products from a PC or an API.

In a standard configuration, an RS485 link enables the interconnection of 32 products to a PC or an automaton over a distance of 1200 meters.



6.2. Recommendations

It is necessary to use a shielded twisted pair (LIYCY type). In a disturbed environment or large network (in terms of length) we recommend the use of a shielded twisted pair (type LIYCY-CY).

A repeater should be used if the distance of 1200 m and/or maximum number of 32 products are exceeded.

A 120 ohms resistance must be fixed at both ends of the link.

6.3. Communication structure

The MODBUS® used by the product involves a dialogue using a master-slave structure. The mode of communication is the RTU (Remote Terminal Unit) using hexadecimal characters of at least 8 bits.

Structure of the MODBUS® sequence (question master -> slave):

Slave address	Function code	Address	Number of words to be read	CRC 16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

According to the MODBUS® protocol, transmission time must be less than 3 silences, i.e. the emission time of 3 characters so that the message is processed by the **DIRIS A17**.

To use this information correctly, it is necessary to use the MODBUS® functions according to the codes:

- 3 : to read n words (maximum 128).
- 6 : to write one word.
- 16 : to write n words (maximum 128).

Note:

1 word<=> 2 octets <=> 16 bits

2 word<=> 4 octets <=> 32 bits

When selecting the slave address 0, a message is sent to all the devices present on the network (only for functions 6 and 16).

Note: The response time (time out question/answer) is 250 ms.

6.4. Register table

The communication tables and associated explanations are available in the documentations page of **DIRIS A17** on internet web site at the following address:

www.socomec.com/en/documentation-diris-a17




7. Programming

Programming can be achieved from the Easy Config configuration software or directly from the **DIRIS A17** display. Refer to following paragraphs for programming from the display.


7.1. Navigation principle

The programming mode allows to modify parameters such as network type, integration time, input/output, alarms or communication parameters. The process to navigate inside the programming mode is described in the following steps:



7.2. Access to programming mode

By pressing "E/PROG" button for 3 seconds, device will enter the programming mode. Default code is: 100.




If the entered code is the right one, device will enter programming mode successfully and remains in this mode until user finishes the session by pressing "PROG" button for 3 seconds.

Attention: For a timeout of 60 seconds without activity on the pushbuttons the device leaves the programming mode without saving possible changes.

7.3. Example: network selection.

In programming mode (see page 10), go to screen "Network type - nEt"


In this example, network change from 4NBL to 3NBL:



7.4. Example: choice of current transformer

In programming mode (see page 10), access to screen "Current transformer - Ct"


Example: ratio change to 500/1.



7.5. Programming mode overview

By pressing "E/PROG" button for 3 seconds, device will enter the programming mode. Default code is: 100.

Different screens are accessed by pressing "PROG":



7.6. Detailed view of the programming menu

Programming mode

PROG E x 1 sec

Code 888

PROG I ▲ / TEST

100 (factory code)

Current transformer

PROG Et SEC SA

1 A, 5 A

Voltage transformer

PROG Ut NO Yes, No

Network type

PROG net 4nbl

3BL, 3NBL, 4BL,
4NBL

Current transformer

PROG Et Pr 1200

5 A 0 -> 10 000 A


Voltage transformer

PROG Ut P 020000 230 V
0 -> 400 000 V

Voltage transformer

PROG Ut S 190 60, 100, 110, 115,
120, 173, **190 V**

XX = default value

 I Δ / TEST		
Max. current integration time		
t_{IRE}	20	
PROG		20, 30, 60, 2, 5, 8, 10, 15 min
		
Max. power integration time		
t_{IRE}	P	
PROG	10	
20, 30, 60, 2, 5, 8, 10, 15 min		
		
Active / reactive energy reset		
rSET	rSET	
PROG	EA	
rSET	rSET	
PROG	Er	
rSET	rSET	
PROG	n0	
Yes, No		
		
Power max reset		
rSET	rSET	
PROG	P	
rSET	rSET	
PROG	n0	
Yes, No		
		
Current max reset		
rSET	31	
PROG	n0	
Yes, No		
		
Pulse meter reset		
rSET	PULS	
PROG	n0	
Yes, No		
		
Input type (IN)		
In	Type	
PROG	PULS	
<i>No: no activation</i> <i>Puls: pulse</i> <i>cd: status change</i> No, puls, cd		
		
Output type (OUT)		
Out	Type	
PROG	EA	
<i>Ea: active energy</i> <i>Er: reactive energy</i> <i>Alarm: status change if alarm</i> EA, ER, Alarm		

XX = default value

Alarm type

ALAR	TYPE	<i>Value alarm</i>
PROG	I	I, In, P , Q, S, Capacitive PF, Inductive PF, THDI, THDU, THDV, cd

Alarm high threshold

ALAR	Ht	
PROG	1330	
	237	0 -> 9999

Alarm low threshold

ALAR	Lt	
PROG	0459	
	223	0 -> 9999

Alarm hysteresis threshold

ALAR	Hyst	
PROG	15	
	1%	0% -> 99%

Alarm delay

ALAR	DELP	
PROG	600	
	2,4 sec	0.01 -> 99.9 sec

Output (OUT) activation in case of alarm

ALAR	oU	
PROG	00	
	Yes, No	


Pulse output energy value

PULS	VAL	
PROG	100	
	0: 0.1 kWh/kvarh 1: 1 kWh/kvarh 2: 10 kWh/kvarh 3: 100 kWh/kvarh 4: 1000 kWh/kvarh 5: 10000 kWh/ kvarh	

Pulse output duration value

PULS	dur	
PROG	200	
	100 -> 900 msec	


XX = default value

 <p>Communication</p> <table border="1"> <tr> <td>PROG</td><td>E0A Adr 123</td><td>Product address on MODBUS network 1 -> 247</td></tr> </table>			PROG	E0A Adr 123	Product address on MODBUS network 1 -> 247			
PROG	E0A Adr 123	Product address on MODBUS network 1 -> 247						
 <p>Backlit</p> <table border="1"> <tr> <td>PROG</td><td>bAC Lit Std</td><td>Standard: remains ON Auxiliary: switches OFF after a few seconds Standard, Auxiliary</td></tr> </table>		PROG	bAC Lit Std	Standard: remains ON Auxiliary: switches OFF after a few seconds Standard, Auxiliary				
PROG	bAC Lit Std	Standard: remains ON Auxiliary: switches OFF after a few seconds Standard, Auxiliary						
 <p>Communication</p> <table border="1"> <tr> <td>PROG</td><td>E0A bdS 96</td><td>Baud Rate 1.2, 2.4, 4.8, 9.6, 19.2, 38.4 kbaud</td></tr> </table>		PROG	E0A bdS 96	Baud Rate 1.2, 2.4, 4.8, 9.6 , 19.2, 38.4 kbaud	<p>Program password</p> <table border="1"> <tr> <td>PROG</td><td>PASS CHG 250</td><td>100 0 -> 999</td></tr> </table>	PROG	PASS CHG 250	100 0 -> 999
PROG	E0A bdS 96	Baud Rate 1.2, 2.4, 4.8, 9.6 , 19.2, 38.4 kbaud						
PROG	PASS CHG 250	100 0 -> 999						
 <p>Communication</p> <table border="1"> <tr> <td>PROG</td><td>E0A Par n0</td><td>Parity No, Even, Odd</td></tr> </table>		PROG	E0A Par n0	Parity No, Even, Odd	<p>Serial number</p> <table border="1"> <tr> <td>PROG</td><td>E131 6101 0012</td><td></td></tr> </table>	PROG	E131 6101 0012	
PROG	E0A Par n0	Parity No, Even, Odd						
PROG	E131 6101 0012							
 <p>Communication</p> <table border="1"> <tr> <td>PROG</td><td>E0A St DP</td><td>Stop bit 1, 2</td></tr> </table>		PROG	E0A St DP	Stop bit 1, 2	<p>Software version</p> <table border="1"> <tr> <td>PROG</td><td>SOFT U104</td><td></td></tr> </table>	PROG	SOFT U104	
PROG	E0A St DP	Stop bit 1, 2						
PROG	SOFT U104							


XX = default value

8. Use


The measurement values are accessible via dedicated buttons: **Current**, **Voltage**, **Power** and **Energy**. By pressing the appropriate button several times all the measurement relative to this button can be displayed. All the available measurements are described in the following diagram:

Current	Voltage	Power	Energy
			
Instantaneous phase currents	Instantaneous phase-phase voltages	Total powers - imported/exported active, - imported/exported reactive - apparent	Import active energy
Instantaneous neutral current	Instantaneous phase-neutral voltages	Instantaneous active power per phase	Import reactive energy
Max. phase currents	Instantaneous frequency	Instantaneous reactive power per phase	Apparent energy
Max neutral current	Instantaneous phase-phase voltages THD	Instantaneous apparent power per phase	Export active energy
Max. phase currents THD	Instantaneous phase-neutral voltages THD	Maximum active, reactive and apparent power	Export reactive energy
THD neutral current		Total power factor	Pulse meter connected to the input
		Instantaneous power factor per phase	


8.1. Detailed view of the "Current" menu




8.2. Detailed view of the "Voltage" menu



8.3. Detailed view of the "Power" menu



8.4. Detailed view of the "Energy" menu



9. Connection test function

During the test, the DIRIS must have current and voltage for each of the phases.

In addition to this, the function recognises the PF of the installation as being between $0.6 < \text{PF} < 1$. If the PF of the installation is not within this range, this function cannot be used.


- In 4 BL / 3 BL, only the connection of the CTs is controlled.
- In 4NBL and 3NBL the connection as a whole is controlled.





- Err 0 = no error
- Err 1 = CT phase 1 inverted
- Err 2 = CT phase 2 inverted
- Err 3 = CT phase 3 inverted
- Err 4 = V1 and V2 voltages inverted
- Err 5 = V2 and V3 voltages inverted
- Err 6 = V3 and V1 voltages inverted

- Errors 1, 2 and 3 must be corrected manually by reversing CT connections.
- Errors 4, 5 and 6 must be corrected manually by modifying voltage connections.

First test operation


Press the TEST button for 3 seconds. The error indication is displayed on the screen.





Second test operation

Note: this menu only appears if the test has already been done.

 ▲ / TEST														
<p>tEST dONE</p> <p>rE TEST NO</p>		To perform the test a second time												
 ▼														
<p>tEST dONE</p> <p>rE TEST YES</p>		To start the second test, change the value to YES												
 OK														
<p>tEST Err 0</p>		Err 0 = no error												
 ▲ / TEST														
<table border="1"> <tr> <td></td> <td>C1 - 0.0000 MVA</td> </tr> <tr> <td></td> <td>C2N - 0.0000 MVA</td> </tr> <tr> <td></td> <td>C2 - 0.0000 PF Hz</td> </tr> <tr> <td></td> <td>C3 - 0.0000 MVA</td> </tr> <tr> <td></td> <td>C3 - 0.0000 PF</td> </tr> <tr> <td></td> <td>C3-1 - 0.0000 MVA</td> </tr> </table> <p>88 + MVAh</p>			C1 - 0.0000 MVA		C2N - 0.0000 MVA		C2 - 0.0000 PF Hz		C3 - 0.0000 MVA		C3 - 0.0000 PF		C3-1 - 0.0000 MVA	To quit Test mode and return to the screen displayed before the test.
	C1 - 0.0000 MVA													
	C2N - 0.0000 MVA													
	C2 - 0.0000 PF Hz													
	C3 - 0.0000 MVA													
	C3 - 0.0000 PF													
	C3-1 - 0.0000 MVA													



10. Assistance

Causes	Solutions
Backlight switched off	Check backlight configuration
Voltages displayed = 0 V or incorrect	Verify the connections and the CT configuration.
Currents displayed = 0 A or incorrect	Verify the connections Verify the CT configuration
Powers and power-factor (PF)	Use the test connection function (see page 23)
Phases missing on Display	Check the network configuration (see page 11)
I/O are not operating	Check power supply 8 - 30VDC

11. Electrical and Technical characteristics

Type	Panel mounting
Dimensions W x H x D	72 x 72 x 60 mm
Case degree of protection	IP30
Front degree of protection	IP52
Display type	backlit LCD display
Terminal block type	fixed or plug-in
Voltage and other connection cross-section	0.2 ... 2.5 mm ²
Current connection cross-section	0.5 ... 6 mm ²
Weight	400 g

Current measurement (TRMS)

Via CT with primary up to	9 999 A
Via CT with secundary	1 or 5 A
Measurement range	0 ... 11 kA
Input consumption	0.6 VA
Measurement updating period	1 s
Accuracy at 50 Hz	0,5 %
Accuracy at 60 Hz	1 %
Permanent overload	6 A
Intermittent overload	10 I _n for 1 s

Voltage measurements (TRMS)

Direct measurement between phases	50 ... 500 VAC
Direct measurement between phase and neutral	28 ... 289 VAC
VT primary	400 000 VAC
VT secondary	60, 100, 110, 173, 190 VAC
Input consumption	≤ 0.1 VA
Measurement updating period	1 s
Accuracy at 50 Hz	0,5 %
Accuracy at 60 Hz	1 %
Permanent overload	800 VAC

Power measurement

Measurement updating period	1 s
Accuracy at 50 Hz	1 %
Accuracy at 60 Hz	2 %

Power factor measurement

Measurement updating period	1 s
Accuracy at 50 Hz	0,5 %
Accuracy at 60 Hz	1 %

Frequency measurement

Measurement range	45 ... 65 Hz
Measurement updating period	1 s
Accuracy	0,1 %

Energy accuracy

Active (as per IEC 62053-21) at 50 Hz	Class 1
Active (as per IEC 62053-21) at 60 Hz	Class 2
Reactive (according to IEC 62053-23)	Class 2

Operating conditions

Operating temperature	- 10 ... + 55 °C
Storage temperature range	- 20 ... + 85 °C
Relative humidity	95 %

Auxiliary power supply

Alternating voltage	220 ... 277 VAC
AC tolerance	± 15 %
Frequency	50 / 60 Hz
Consumption	3 VA

Digital pulse and control input

Number	1
Type of power supply	Optocoupler 8 to 30 VDC
Minimum signal width	10 ms
Minimum duration between 2 pulses	18 ms

Communication

Link	RS485
Type	2 ... 3 half duplex wires
Protocol	MODBUS RTU
MODBUS® speed	1200 ... 38400 bauds

Pulse, alarm and control output

Number	1
Type of power supply	Optocoupler 8 to 30 VDC
Minimum signal width	10 ms
Minimum duration between 2 pulses	18 ms
Type of optocoupler	IEC 62053-31 Class A (5 ... 30 VDC)
Pulse weight	100 Wh, 1 kWh, 10 kWh, 100 kWh, 1000 kWh, 10000 kWh
Pulse length	100 ms, 200 ms, 300 ms, ..., 900 ms

12. According to IEC 61557-12

IEC 61557-12 Edition 1 (08/2007) COMPLIANCE

Performance criteria	
PMD classification	SD
Temperature	K55

CHARACTERISTICS OF THE FUNCTIONS

Symbol for functions	Measurement range	Operational performance class
P	10% to 120% In	1
Qa, Qv	10% to 120% In	1
Sa, Sv	10% to 120% In	1
Ea	0 to 99999999 kwh	1
Era, Erv	0 to 99999999 kwh	2
Eapa, Eapv	-	
f	45 to 65 Hz	0,1
I	10% to 120% In	0,5
IN	-	
INc	10% to 120% In	1
U	46 to 520Vac ph/ph	0,5
Pfa, Pfv	0.5 ind to 0.8 cap	0,5
Pst, Plt	-	
Udip, Uswl	-	
Utr, Uint	-	
Unba, Unb	-	
Un	-	
THDu	Fn = 50Hz - ranks 1 to 31 Fn = 60Hz - ranks 1 to 31	1
THD-Ru	-	
Ih	-	
THDi	Fn = 50Hz - ranks 1 to 31 Fn = 60Hz - ranks 1 to 31	1
THD-Ri	-	
Msv	-	

13. Glossary of abbreviations

nEt	Type of network
4NBL	Unbalanced three-phase network, 4 wires with 3 CT
4BL	Balanced three-phase network, 4 wires with 1 CT
3NBL	Unbalanced three-phase network, 3 wires with 2 or 3 CT
3BL	Balanced three-phase network, 3 wires with 1 CT
Ct	Current transformer
MAX	Maximum average values
tIME 4I	Integration times for average and maximum current values
tIME P	Integration times for mean and maximum power values
rSET	Reset
MAX P	Active power maximum mean value
EA	Active energy (kWh)
ER	Reactive energy (kvarh)
AUX	Auxiliary supply
bACLit	Backlit
SErl	Serial number
SOFt	Software version
THD I1, I2, I3, In	Current harmonic distortion rate
THD U12, U23, U31	Phase-to-phase voltage harmonic distortion rate
THD V1, V2, V3	Phase-to-neutral voltage harmonic distortion rate
COM	Communication
ADR	Slave address
BDS	Communication speed (baud)
PAR	Communication frame parity
NO	Without parity
Even	Even parity
Odd	Odd parity
STOP	Frame-stop beep
1	1 stop bit
2	2 stop bits

Socomec worldwide

IN EUROPE

BELGIUM

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power Power
Tel. +32 2 340 02 30
Fax +32 2 346 28 99
info.be@socomec.com

FRANCE

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +33 1 45 14 63 00
Fax +33 1 48 67 31 12
dcm.ups.fr@socomec.com

GERMANY

Critical Power
Tel. +49 621 71 68 40
Fax +49 621 71 68 444
info.ups.de@socomec.com
Power Control & Safety / Energy Efficiency
Tel. +49 7243 65292 0
Fax +49 7243 65292 13
info.scp.de@socomec.com

ITALY

Critical Power
Tel. +39 02 98 242 942
Fax +39 02 98 240 723
info.ups.it@socomec.com
Power Control & Safety / Energy Efficiency
Tel. +39 02 98 49 821
Fax +39 02 98 24 33 10
info.scp.it@socomec.com
Solar Power
Tel. +39 0444 598611
Fax +39 0444 598627
info.solar.it@socomec.com

NETHERLANDS

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +31 30 760 0900
Fax +31 30 637 2166
info.nl@socomec.com

POLAND

Critical Power
Tel. +48 22 825 73 60
Fax. +48 22 825 73 60
info.ups.pl@socomec.com
Power Control & Safety / Energy Efficiency
Tel. +48 91 442 64 11
Fax +48 91 442 64 19
info.scp.pl@socomec.com

PORTUGAL

Critical Power / Solar Power
Tel. +351 261 812 599
Fax +351 261 812 570
info.ups.pt@socomec.com

ROMANIA

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +40 21 319 36 88
Fax +40 21 319 36 89
info.ro@socomec.com

RUSSIA

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +7 495 775 19 85
Fax +7 495 775 19 85
info.ru@socomec.com

SLOVENIA

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +386 1 5807 860
Fax +386 1 561 11 73
info.si@socomec.com

SPAIN

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +34 93 540 75 75
Fax +34 93 540 75 76
info.es@socomec.com

TURKEY

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +90 216 540 71 20-21-22
Fax +90 216 540 71 27
info.tr@socomec.com

UNITED KINGDOM

Critical Power
Tel. +44 1285 863 300
Fax +44 1285 862 304
info.ups.uk@socomec.com
Power Control & Safety / Energy Efficiency
Tel. +44 1462 440 033
Fax +44 1462 431 143
info.scp.uk@socomec.com

IN ASIA PACIFIC

AUSTRALIA

Critical Power / Power Control & Safety
Tel. +61 2 9325 3900
Fax +61 2 9888 9544
info.ups.au@socomec.com

CHINA

Critical Power / Power Control & Safety / Energy Efficiency
Tel. +86 21 52 98 95 55
Fax +86 21 62 28 34 68
info.cn@socomec.com

INDIA

Critical Power / Solar Power
Tel. +91 44 39215400
Fax +91 44 39215450 & 51
info.ups.in@socomec.com
info.solar.in@socomec.com

Power Control & Safety / Energy Efficiency

Tel. +91 124 4027210
Fax +91 124 4562738
info.scp.in@socomec.com

SINGAPORE

Critical Power / Power Control & Safety / Energy Efficiency
Tel. +65 6506 7600
Fax +65 64 58 7377
info.sg@socomec.com

THAILAND

Critical Power
Tel. +66 2 941 1644 7
Fax +66 2 941 1650
info.ups.th@socomec.com

VIETNAM

Critical Power
Tel. +84 8 3559 1220
Fax +84 8 3559 1221
info.ups.vn@socomec.com

IN MIDDLE EAST

UNITED ARAB EMIRATES

Critical Power / Power Control & Safety / Energy Efficiency / Solar Power
Tel. +971 4 29 98 441
Fax +971 4 29 98 449
info.ae@socomec.com

IN AMERICA

USA, CANADA & MEXICO

Power Control & Safety / Energy Efficiency
Tel. +1 617 245 0437
Fax +1 617 245 0437
info.us@socomec.com

OTHER COUNTRIES

NORTH AFRICA

Algeria / Morocco / Tunisia
info.naf@socomec.com

AFRICA

Other countries
info.africa@socomec.com

SOUTH EUROPE

Cyprus / Greece / Israel / Malta
info.se@socomec.com

SOUTH AMERICA

Tel. +34 93 540 75 75
info.es@socomec.com

MORE DETAILS

www.socomec.com/worldwide

HEAD OFFICE

SOCOME GROUP

S.A. SOCOME Capital 10 816 800€
R.C.S. Strasbourg B 548 500 149
B.P. 60010 - 1, rue de Westhouse
F-67235 Benfeld Cedex - FRANCE
Tel. +33 3 88 57 41 41
Fax +33 3 88 74 08 00
info.scp.isd@socomec.com

www.socomec.com



ENERGY
SPECIALIST
922

YOUR DISTRIBUTOR