ATP Cummins - Leroy Somer Series

| | | OWE |
|------------|-----|---------------|
| • | ^ | NTIC P |
| _ ▲ | -41 | ATLANTIC POWE |
| | | *• |
| | | |

ATP1250-CMM/LS

Main Features



| Standby Power (STP) | 1250 kVA | 1000 kW |
|------------------------|----------|---------|
| Continuous Power (PRP) | 1136 kVA | 909 kW |
| Continuous Power (COP) | - kVA | - kW |

Soundproof

| Length (L) | 5800 mm | |
|--|-------------|---------------------------------------|
| Height (H) | 2500 mm | |
| Width (W) | 2280 mm | I I I I I I I I I I I I I I I I I I I |
| Weight | 11600 kg | |
| Daily deposit | 1930 L | WL |
| | 50Hz | |
| Diesel engine | 113.6 dB(A) | |
| Noise test performed at 100% of ESP power, at a distance of 1 m, with the engine without a radiator, without a cooling fan, and without a silencer. | | |

Installation in room

| Sistema de escape | Sistema de escape 50Hz | | |
|--|------------------------|-----|-----|
| | COP | PRP | STP |
| Maximum backpressure (kPa) | 10 | | |
| Maximum static weight supported on the turbocharger outlet flange (N.m) - | | - | |
| Maximum intake air restriction with heavy-duty air filter | | - | |
| Dirty Element (kPa) Clean Element (kPa) | | - | |
| Max. exhaust pipe diameter (mm) 152 | | | |


| Fuel System | | 50Hz | |
|--|-----|------|-------|
| | COP | PRP | STP |
| Maximum allowed restriction (kPa) | - | - | 13,55 |
| Maximum allowed restriction for the PT fuel pump with check valves (kPa) | 22 | | |
| Minimum allowed fuel tank ventilation capacity (L/h) | | | 425 |

| Electric System | Electric System 50Hz | | |
|---|----------------------|-----|-----|
| | COP | PRP | STP |
| Starter engine (Vdc) | 24 | | |
| Battery charging system, negative ground (A) | A) 35 | | |
| Maximum allowed resistance of the starting circuit $\left(\Omega\right)$ | 0,002 | | |
| inimum recommended battery capacity — 1800 old soak @ 0 to 32°F (-18 to 0°C) | | | |



Engine specifications

| General specifications | 50 Hz |
|-------------------------------------|---------------------------------|
| Model | KTA38-G9 |
| Emissions | Not applicable |
| Performance Grade | G2 |
| Operating Method | Four-stroke |
| Fuel Type | Diesel |
| Cooling System | Liquid (water + 50% antifreeze) |
| Aspiration System | Turbocharged |
| Injection System | Direct injection Cummins PT |
| Number and Arrangement of Cylinders | V12 |
| Displacement (L) | 38,0 |
| Cylinder Bore (mm) | 159 |
| Cylinder Stroke (mm) | 159 |
| Compression Ratio | 14.5:1 |
| Regulation | Electronic |
| Rotational Speed | 1500 |
| Oil Capacity (L) | 222,3 |
| Gross Power COP (kWm) | - |
| Gross Power PRP (kWm) | - |
| Gross Power STP (kWm) | 1090 |
| Coolant Capacity (L) | 170,3 |
| Net Power COP (kWm) | - |
| Net Power PRP (kWm) | - |
| Net Power STP (kWm) | - |



| Consumption | | 60Hz | |
|--------------------------------|--------|-------|-------|
| Fuel consumption | Charge | lt/h | g/kWh |
| STP | 100% | 251 | 193 |
| | 100% | - | - |
| PRP | 75% | - | - |
| РКР | 50% | - | - |
| | 25% | - | - |
| Fuel supply flow (L/h) | | 251 | |
| Condiciones de refe | rencia | | |
| Temperature (°C) | | 25 | |
| Atmospheric pressure (kPa) | | 100 | |
| Sistema de arranque | | | |
| Voltage (V) | | 24 | |
| Standard thermostat range (°C) | | 82-93 | |

Alternator specifications

| General specifications | |
|-----------------------------------|-------------|
| Model | LSA50.2M6 |
| Number of Phases | Three-phase |
| Protection | IP23 |
| Insulation | н |
| Heating | Н |
| Airflow 50 Hz (m ³ /s) | 1,8 |
| Waveform NEMA = TIF: | TIF<50 |
| Coupling | Flex plate |
| Support | Monopalier |



| No-load waveform distortion | < 3.5% |
|--|------------|
| Load waveform distortion | < 3.5% |
| Number of windings | 6 |
| Excitation (standard / option) | AREP / PMG |
| AVR Model (standard / option) | D350 |
| Voltage Regulation (standard / option) | ± 0.25% |

Starter Battery

| | Battery voltage | |
|-----|------------------|--|
| + - | Battery Capacity | |
| | Amount | |
| | Battery type | Libre de mantenimiento, tipo plomo-ácido sellada |


Certifications





www.atlanticpowerenergy.com Copyright © 2021 Atlantic Power Energy - All rights reserved

Control Panel





| Generator | DSE6110/20 |
|------------------------------------|------------|
| Tension (F-F / F-N) | */* |
| Intensity | * |
| Frequency | * |
| RMS values | * |
| Generator phase sequence | * |
| Generator ground current [1] | * |
| Number of events registered | 250 |
| Integrated clock | * |
| PIN protection | * |
| kWh, kVAr, kVAh, kVArh, cos Ø | * |
| Synchronoscope (m) | * |
| Number of available departures [2] | 6 |
| Engine running hours | * |
| Alarm i ndication on LCD | * |
| Total number of LED indicators | 8 |
| No. of LED alarms | X |
| Acoustic alarm signaling | |
| Programmer | * |
| Fuel level | * |
| Engine | DSE6110/20 |
| Engine speed | * |
| Low oil pressure protection | * |
| Oil pressure reading [3] | |
| High engine temperature protection | * |
| Engine temperature reading[3] | |
| Battery voltage | * |
| Battery Intensification [4] | - |
| Fuel consumption [5] | * |
| Low water level in radiator [6] | |
| Scheduled maintenance for engine | * |
| Communication | DSE6110/20 |
| USB Type B Female Port (Max. 6m) | * |
| [7] USB Type A Female Port (n) | X |
| CAN port (Max. 40m) | * |
| | |
| PLC function | * |

| GridDSEG110/20Tension (F-F / F-N)★Intensity [1]☑Frequency★kVA,kW, cos Ø (a)☑Network-group switching control★Protections and alarmsDSEG110/20High/low battery voltage♀Battery charging alternator failure♀Stop failure♀/.Boot failure♀/.Low fuel level♀/.Overload♀/.Asymmetry between phases♀/.High/Low Generator Frequency♀/.High/Low Generator Frequency♀/.Engine overspeed♀/.Low voltage in generator♀/.Storge♀/.Low voltage in generator♀/.Low voltage in generator♀/.Storge♀/.Low voltage in generator♀/.ECU Alert (if applicable)♀/.Low oil pressure♀/.Low oil pressure♀/. |
|--|
| Intensity [1] ⊠ Frequency ★ kVA,kW, cos Ø (a) ⊠ Network-group switching control ★ Protections and alarms DSE6110/20 High/low battery voltage ↓ Battery charging alternator failure ↓ Stop failure ↓/ ③ Boot failure ↓/ ③ Overload ↓/ ③ Ground fault ↓ / ③ Asymmetry between phases ↓ / ③ High/Low Generator Frequency ↓ / ③ High/Low Generator Frequency ↓ / ③ Low engine speed ↓ / ③ Storg ↓ / ③ Low voltage in generator ↓ / ③ Ecu Alert (if applicable) ↓ / ③ |
| Frequency ★ kVA,kW, cos Ø (a) ☑ Network-group switching control ★ Protections and alarms DSE6110/20 High/low battery voltage ♀ Battery charging alternator failure ♀ Stop failure ♀/○ Boot failure ♀/○ Low fuel level ♀/○ Overload ♀/○ Asymmetry between phases ♀/○ Maintenance ♀/○ High/Low Generator Frequency ♀/○ Low engine speed ♀/○ Storge ♀/○ Low voltage in generator ♀/○ ECU Alert (if applicable) ♀/○ |
| kVA,kW, cos Ø (a) Image: Comparison of |
| Network-group switching control ★ Protections and alarms DSE6110/20 High/low battery voltage ↓ Battery charging alternator failure ↓ Stop failure ↓/. Boot failure ↓/. Low fuel level ↓/. Overload ↓/. Ground fault ↓/. Asymmetry between phases ↓/. High/Low Generator Frequency ↓/. Engine overspeed ↓/. Low engine speed ↓/. Surge ↓/. Low voltage in generator ↓/. ECU Alert (if applicable) ↓/. |
| Protections and alarms DSE6110/20 High/low battery voltage Q Battery charging alternator failure Q Stop failure Q/③ Boot failure Q/③ Low fuel level Q/③ Overload Q/③ Ground fault Q/③ Asymmetry between phases Q/③ High/Low Generator Frequency Q/③ Engine overspeed Q/③ Low voltage in generator Q/③ ECU Alert (if applicable) Q/③ |
| High/low battery voltage Q Battery charging alternator failure Q Stop failure Q/0 Boot failure Q/0 Low fuel level Q/0 Overload Q/0 Ground fault Q/0 Asymmetry between phases Q/0 High/Low Generator Frequency Q/0 Engine overspeed Q/0 Low engine speed Q/0 Strage Q/0 Eucy voltage in generator Q/0 ECU Alert (if applicable) Q/0 |
| Battery charging alternator failure |
| Stop failure \$\overline\$/\$\overline\$ Boot failure \$\overline\$/\$\overline\$ Low fuel level \$\overline\$/\$\overline\$ Overload \$\overline\$/\$\overline\$ Ground fault \$\overline\$/\$\overline\$ Asymmetry between phases \$\overline\$/\$\overline\$ Maintenance \$\overline\$/\$\overline\$ High/Low Generator Frequency \$\overline\$/\$\overline\$ Low engine speed \$\overline\$/\$\overline\$ Surge \$\overline\$/\$\overline\$ Low voltage in generator \$\overline\$/\$\overline\$ ECU Alert (if applicable) \$\overline\$ |
| Boot failure Q/O Boot failure Q/O Low fuel level Q/O Overload Q/O Ground fault Q/O Asymmetry between phases Q/O Maintenance Q/O High/Low Generator Frequency Q/O Engine overspeed Q/O Low engine speed Q/O Surge Q/O Low voltage in generator Q/O ECU Alert (if applicable) Q/O |
| Low fuel level \$\bar{\overline{\phi}}\$ Overload \$\bar{\overline{\phi}}\$ Ground fault \$\bar{\overline{\phi}}\$ Asymmetry between phases \$\bar{\overline{\phi}}\$ Maintenance \$\bar{\overline{\phi}}\$ High/Low Generator Frequency \$\bar{\overline{\phi}}\$ Engine overspeed \$\bar{\overline{\phi}}\$ Low engine speed \$\bar{\overline{\phi}}\$ Surge \$\bar{\overline{\phi}}\$ Low voltage in generator \$\bar{\overline{\phi}}\$ ECU Alert (if applicable) \$\bar{\overline{\phi}}\$ |
| Overload Q/0 Ground fault Q/0 Asymmetry between phases Q/0 Maintenance Q/0 High/Low Generator Frequency Q/0 Engine overspeed Q/0 Low engine speed Q/0 Surge Q/0 Low voltage in generator Q/0 ECU Alert (if applicable) Q/0 |
| Ground fault \$\overline\$/\$\overline\$ Asymmetry between phases \$\overline\$/\$\overline\$ Maintenance \$\overline\$/\$\overline\$ High/Low Generator Frequency \$\overline\$/\$\overline\$ Engine overspeed \$\overline\$/\$\overline\$ Low engine speed \$\overline\$/\$\overline\$ Surge \$\overline\$/\$\overline\$ Low voltage in generator \$\overline\$/\$\overline\$ ECU Alert (if applicable) \$\overline\$/\$\overline\$ |
| Asymmetry between phases Q/③ Maintenance Q/③ High/Low Generator Frequency Q/③ Engine overspeed Q/⑥ Low engine speed Q/⑥ Surge Q/⑥ Low voltage in generator Q/⑥ ECU Alert (if applicable) Q/⑧ |
| Maintenance ♀/⊗ High/Low Generator Frequency ♀/⊗ Engine overspeed ♀/⊗ Low engine speed ♀/⊗ Surge ♀/⊗ Low voltage in generator ♀/⊗ ECU Alert (if applicable) ♀/⊗ |
| High/Low Generator Frequency ↓/☉ Engine overspeed ↓/☉ Low engine speed ↓/☉ Surge ↓/☉ Low voltage in generator ↓/☉ ECU Alert (if applicable) ↓/☉ |
| Engine overspeed ↓/⊗ Low engine speed ↓/⊗ Surge ↓/⊗ Low voltage in generator ↓/⊗ ECU Alert (if applicable) ↓/⊗ |
| Low engine speed ♀/⊙ Surge ♀/⊙ Low voltage in generator ♀/⊙ ECU Alert (if applicable) ♀/⊙ |
| Surge ↓/⊗ Low voltage in generator ↓/⊙ ECU Alert (if applicable) ↓/⊗ |
| Low voltage in generator ♀/⊗ ECU Alert (if applicable) ♀/⊗ |
| ECU Alert (if applicable) ♀/⊗ |
| |
| Low oil pressure Q / ③ |
| |
| Low water I evel in radiator [f] \bigcirc / \otimes |
| High engine temperature ♀/⊗ |
| Fuel leak/theft Q |
| Aplications DSE6110/20 |
| Automatic or manual start * |
| Remote start by dry contact NA * |
| Automatic due to network failure |
| Alternation with distributed time |
| Multi-generators in synchronism with load (Max 32 generators) (m) |
| Generator-grid i n synchronism and with load sharing (1 generator and 1 grid) (m) |
| Optional Expansions DSE6110/20 |
| DSE2130 (8 digital inputs) I G-IOM (8 digital inputs/outputs + 4 analog inputs)I G-08 (8 ent. dig.) |
| DSE2157 I -RB8 G-06 (8 relay outputs) |
| DSE2548 IGL-RA15 - (expansion with 8 Additional LEDs * |
| DSE2510/20 (mirror controller, max distance 1km) * |
| Rules |
| Working temperature -30 -> 70°C |
| Protection index (when mounted with sealing gasket) IP65 |
| Maximum humidity level (for 48 h) 93% / 40°C |



Legend

| * | Available | [4] | Needs an additional ammeter |
|-----|--|------|--|
| - | Optional | [5] | If the information is provided by the engine ECU |
| X | Not available | [6] | Requires an additional sensor |
| Q | Warning alarm | [7] | Need to include an additional IL-NT-S-USB module |
| ⊗ | Stop alarm | [8] | Need to include an additional IL-NT-RS232-485 module |
| [1] | Need an additional IT | [9] | DeepSea: Needs to include an additional DSE891 module/ComAp: Needs to include an additional IB-LITE module |
| [2] | Number of outputs available for standard configuration. Outputs do not include relays or additional wiring to terminals. | [10] | DeepSea: Needs to include an additional DSE890 module/ComAp: Needs to include an additional IL-NT-GPRS module |
| [3] | If the information is not provided by the engine ECU, an additional sensor needs to be included. | [11] | DeepSea: Needs to include an additional DSE892 module/ComAp: Needs to include an additional IB-LITE module |

Emergency Standby Power (ESP)

Emergency standby power is the maximum power available to a variable load during a main power grid failure. The average load factor over 24 hours of operation must not exceed 70% of the motor's ESP rated power. Typical motor operating hours are 200 hours per year, with a maximum usage of 500 hours per year.

This includes an annual maximum of 25 hours per year at the ESP power rating. Overload capability is not permitted. The motor must not be used for sustained utility parallel applications.

Main Power (PRP)

Prime Power is the maximum power available for unlimited hours of use in a variable load application. The average load factor must not exceed 70% of the motor's PRP rating during any 24-hour period. A 10% overload capability is available; however, it is limited to 1 hour within each 12-hour period.

- 1. All ratings are based on operating conditions according to ISO 8528-1, ISO 3046, DIN6271. Performance tolerance ±5%.
- 2. Test conditions: 100 kPa, 25°C air inlet temperature, 30% relative humidity, with fuel density of 0.84 kg/L. Derating may be required for conditions outside these, contact factory for details.
- 3. Power output curves are based on engine operation with fuel system, water pump and lubricating oil pump; battery charging alternator, fan and optional equipment are not included.

